












Definition of Community WASH Data Indicators




No	Indicator	Definition from M&E Handbook ^{*1}	Photo	How to measure
1	Unsatisfactory latrines	Pit Latrines where walls are missing or do not provide "privacy" for the user (e.g. walls are missing or inadequate) and/or there is no roof	 	Number of Unsatisfactory Latrines
		Hanging toilets		
		Bucket latrine		
		A pit or receptacle of any depth which is not full or over-flowing		



No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
4		Impermeable floor, No DHC	<p>Made of Cement, burnt bricks, plastic or ceramic with cement lining without drop hole cover</p> <p>Impermeable floor: An impermeable latrine floor may be made from <u>cement plaster</u>, <u>concrete</u>, <u>ceramic</u>, <u>fibre glass</u>, <u>metals</u>, <u>plastic</u>, <u>clay tiles/burnt bricks plus motor</u>, or other materials that can be cleaned easily. An impermeable floor must be smooth and solid, have no cracks, perforations, or openings other than the drop-hole.</p>		
5	Improved Latrine	Impermeable floor, with DHC	<p>An improved sanitation facility should have the following characteristics:</p> <ul style="list-style-type: none"> a well constructed and functional pit or receptacle with a minimum depth of 1.0 metre (which is not full or over-flowing), <u>impermeable floor</u> made of concrete, plastic, tiles or burnt brick with cement lining and foot rests a good <u>superstructure with a door, roof</u> and <u>walls</u> (which would offer privacy, comfort, security and dignity for the user) and some other hygienic features such as a <u>tight fitting drop hole cover</u> (which would minimise smell and movement of flies). 		Number of Improved Latrines




No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
6	Compositing Latrines (Ecosan)		<ul style="list-style-type: none"> Well-constructed sub-structure (normally with accessible double holes mostly referred to as vaults); <u>either separates urine from human faeces or not (in extremely dry climates) and safely contains new or fresh faeces separate from composted faeces</u> where urine is separated, it can be stored in containers for use as liquid fertilizer Well-constructed superstructure with walls that provide privacy and roof providing shelter from the rain Where <u>ash</u> and/or <u>soil</u> are used after use. 		Number of Ecosan Latrine
7	Households with flush Toilets		Have running water available, and flush to either a sewer or a septic tank.		Number of flush toilets



No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
8	Hand Washing Facilities	Hand Washing facilities without Soap	<p>A hand washing facility should allow for free flowing water to be released over the hands (e.g. bucket with tap, home plastic water facility, jug and bowl and Soap should also be available next to the hand washing facility</p> <p>Note: HWF with no water do not count</p>		Number of HWFs without soap
9		Hand Washing facilities with Soap	<p>A hand washing facility should allow for free flowing water to be released over the hands (e.g. bucket with tap, home plastic water facility, jug and bowl and Soap should also be available next to the hand washing facility</p> <p>Note: HWF with no water do not count</p>		Number of HWFs with soap
10	Number of households with properly functioning Waste Management system		<p>Households with working refuse pits/ waste bins</p> <p>Note: If no functional, do not count</p>		Number of households with functional waste management system




No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
11	Boreholes	functional with clean surrounding	<ul style="list-style-type: none"> A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if <u>all components of the water extraction system are in good working order.</u> <u>Borehole</u> defined that a hole which has been dug, bored, driven or drilled into the ground to depth of more than 25m for the purpose of extracting water. <u>And surrounding</u> is free from excessive dirt, free from bushes, a soak way pit <u>with stones present.</u> <p><i>Note: if without clean surrounding do not count</i></p>		Number of functional BHs with clean surrounding
12		functional without clean surrounding	<p>A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if all components of the water extraction system are in good working order.</p> <p>And surrounding has excessive dirt, bushes, and a soak way pit <u>without stones present and stagnant water.</u></p>		Number of functional BHs without clean surrounding


No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
13		Non-functional	<p>A water point is considered non-functional if it is not providing water <u>at the time of a spot check.</u></p> <p>This may be as a result of <u>breakdown, vandalism or Abandoned:</u></p>		Number of non-functional boreholes
14	Communal Taps/Kiosks	functional with clean surrounding	<p>A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if all components of the water extraction system are in good working order.</p> <p>And surrounding is free from excessive dirt, free from bushes, <u>a soak way pit with stones present.</u></p> <p><i>Note: if without clean surrounding do not count</i></p>	 	Number of functional communal Taps with clean surrounding


No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
15	functional without clean surrounding		<p>A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if all components of the water extraction system are in good working order.</p> <p>And surrounding has excessive dirt, bushes, a <u>soak way pit without stones present and stagnant water</u></p>	 	Number of functional communal Taps without clean surrounding

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
					
16		Non-functional	<p>A water point is considered non-functional if it is not providing water <u>at the time of a spot check.</u></p> <p>This may be as a result of <u>breakdown, disconnection due to Non-Payment, Vandalism or Abandoned:</u></p>		Number of non-functional communal Tap
17	Individual Taps	Functional	<p>A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if <u>all components of the water extraction system are in good working order</u></p>		Number of functional individual Taps (<u>inside house tap and yard tap</u>)

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
18		Non-functional	<p>A water point is considered non-functional if it is not providing water <u>at the time of a spot check</u>.</p> <p>This may be as a result of <u>breakdown, disconnection due to Non-Payment, Vandalism or Abandoned</u>:</p>		Number of non-functional individual Taps
19	Protected Shallow Wells	functional with clean surrounding	<ul style="list-style-type: none"> A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check. Protected well defines it is protected from <u>runoff water by a well lining or casing</u> that is raised above ground level and <u>a platform</u> that diverts spilled water away from the well. It is also <u>covered</u>, so that bird droppings and animals cannot fall into the well. <small>Source: UNCEF/WHO Joint Monitoring Programme</small> shallow well define that a hole which has been dug, bored, driven or drilled into the ground to depth of less than 25m for the purpose of extracting water. clean surrounding is free from excessive dirt, free from bushes, <u>a soak way pit with stones present</u>. 		Number of protected shallow wells <u>with</u> clean surrounding

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
			<i>Note: if without clean surrounding do not count</i>		
20		functional without clean surrounding	<p>A water point is considered functional if it is providing water at the minimum appropriate flow-rate at the time of a spot check, and if all components of the water extraction system are in good working order.</p> <p>And surrounding has excessive dirt, bushes, and <u>a soak way pit without stones present</u> and stagnant water.</p>		Number of functional protected shallow wells <u>without</u> clean surrounding
21		Non-functional	<p>A water point is considered non-functional if it is not providing water at the time of a spot check. This may be as a result of <u>breakdown, Vandalism or Abandoned:</u></p>		Number of Non-functional protected shallow wells

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
22	Protected Spring	functional with clean surrounding	<p>If it has a soak away pit, apron, and a drain , is located at least 30m from the closest toilet or latrine , and if it has a <u>water-tight concrete cover to protect from runoff.</u></p> <p>And surrounding is free from excessive dirt, free from bushes, <u>a soak way pit with stones</u> present.</p> <p><i>Note: if without clean surrounding do not count</i></p>		Number of functional protected spring <u>with</u> clean surrounding
23		functional without clean surrounding	<p>If it has a soak away pit, apron, and a drain , is located at least 30m from the closest toilet or latrine , and if <u>it has a water-tight concrete cover to protect from runoff.</u></p> <p>And surrounding has excessive dirt, bushes, and <u>a soak way pit without stones</u> and there is stagnant water.</p>		Number of functional protected springs <u>without</u> clean surrounding
24		Non-functional	<p>A water point is considered non-functional if it is not providing water at the time of a spot check. This may be as a result of <i>breakdown, Vandalism or Abandoned:</i></p>		Number of Non-functional protected spring

No	Indicator	Definition from M&E Handbook ^{*1}	Photo	How to measure
25	Triggered with CLTS?	Triggering refers to a process that inspires and empowers rural communities to stop open defecation and to build and use latrines without external support. Triggered either by government or development partners		Yes or No
26	Date triggered	N/A	N/A	Date
27	Date of follow up 1	1 st Supervisory visit to a triggered village with aim of assessing change done <u>by government EWs or development partners</u>	N/A	Date
28	Date of follow up 2	2 nd Supervisory visit to a triggered village with aim of assessing change done <u>by government EWs or development partners</u>	N/A	Date
29	Date of follow up 3	3 rd Supervisory visit to a triggered village with aim of assessing change done <u>by government EWs or development partners</u>	N/A	Date
30	Date of follow up 4	4 th Supervisory visit to a triggered village with aim of assessing change <u>by government EWs or development partners</u>	N/A	Date
31	Verified ODF?	Final supervisory visit to find out if indeed community has stopped open defecation <u>by DCT members or a team of four members one of whom should be from the health sector.</u>	N/A	Yes or No
32	Date declared ODF	Every household uses a latrine with drop hole	N/A	Date

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
	CBM		cover (except for eco-san and VIP types), that offers privacy, and there is no excreta in the open. In this particular case sharing is acceptable		
33		Verified ODF ++?	Every household has and uses a latrine with drop hole cover, superstructure, and hand washing facility. In addition, for a village to qualify for ODF++; <u>all primary and secondary schools, community-based childcare centres, religious institutions, market centres and health centres in the village</u> have latrines with drop hole covers, superstructures, and hand washing facilities	N/A	Yes or No
34		Date declared ODF ++	Done by DCT members and an external/independent person.	N/A	Date
35		No. of WPC/VHWC	Members elected from the water user Communities to regulate, use and care for the water point, collect and manage money to pay for spare parts and repairs	N/A	Number of WPCs and VHWC in the village
36	CBM	No. of functioning and or active WPC/VHWC at this moment	WPC is considered active/ functional <u>if it is able to carry out their roles and responsibility and more especially when their borehole is functional</u>	N/A	Number of active WPCs and VHWC in a village
37		No. of WPC trained in the initial CBM	N/A	N/A	Number of trained WPCs and VHWC in a Village
38		Year trained in initial CBM	N/A	N/A	Date

No	Indicator		Definition from M&E Handbook ^{*1}	Photo	How to measure
39		No. of WPC/VHWC trained in refresher training	N/A	N/A	Number of WPCs and VHWC trained in refresher training.
40		Year trained in CBM refresher course	N/A	N/A	Date
41	AM	No. of preventive maintenance contracts between AM and WPC	This is a <u>service agreement between WPC and AM</u> to be repairing a borehole any time it broken.	N/A	Number of preventive maintenance contracts between WPCs and AM
42		Year of preventive maintenance contract between AM and WPC	N/A	N/A	Date

^{*1} Reference: INDICATORS CONCEPTS AND DEFINITIONS FOR IRRIGATION, WATER AND SANITATION, Ministry of Water Development and Irrigation, 2014